

Hyper-Lite®

Universal AMBER LED Turn Light

Part Numbers: NFYTURN8 (8 LED modules), NFYTURN16 (16 LED modules)

Installation Instructions

Contents: Pair of LED modules, 4 Posi-tap connectors.

1. Locate a flat position where you want to mount the Light Emitting Diodes (LED) modules. The LEDs should point straight out and can be mounted either horizontally or vertically. Ensure wires will reach point of connection.
2. Clean surface where units are to mount (rubbing alcohol works well). Secure the LED modules using the two sided tape on the units. Be careful, tape is not reusable if units are removed after being secured. Two sided tape can be obtained at your local automobile trim shop or parts store.
3. Trim the Yellow wires from the LED modules, if required. Use a Posi-Tap to connect the **YELLOW** wires to the turn signal positive wire on their respective sides.
4. Use a Posi-Tap to connect the Hyper-Lite **BROWN** wire to any good ground.
5. If necessary, tie up the wiring using electrical tape or cable ties. Check the wiring to ensure there is no exposure to the wires being cut, pinched or damaged.
6. Test all lights.

Thanks for choosing Hyper-Lites. Ride Safe.

www.hyperlites.com
888.770.1010
tech@hyperlites.com

